

# SAFETY PRECAUTIONS & WARNINGS

**⚠ STOP! Read disclaimer below before operating your RazorBack Retrofit Kit™**

Before normal operation, bolts for the wing hinge are required to be torqued to 37 ft-lbs, and bolts for trip edge are required to be 22 ft-lbs. Failure to do so may result in damage to the plow wing.

## WING HINGE

Before operating, make sure that all of the bolts and nuts circled are torqued to 37 ft-lbs.



## WING TRIP EDGE

Before operating, make sure that all of the bolts and nuts circled are torqued to 22 ft-lbs.

